

How To Install Dome PTZ Camera

- Step 1 : Check the installation environment to ensure it meets the following conditions.
- (1) The thickness of the wall should be sufficient to install expansion screws.
 - (2) The wall should be able to support at least 8 times the weight of accessories such as smart balls and brackets.
 - (3) Check the brackets and expansion screws, as well as other accessories.



Step 2: Drill holes and install expansion screws.

Mark and drill 4 Ø12 holes for the expansion screws at the designated positions on the wall brackets. Insert M8 expansion screws into the drilled holes.



Step 3: Bracket fixed.

After the cable is threaded out of the bracket, tighten 4 nuts onto the expansion screws.

