

# **Quick Guide** H Series Camera



🔀 support@jennov.com



U.S Hotline: +1 3239021978



www.jennov.com(24 Hours Online Service)

## Catalogs

01 Download & Register the Application1
02 Camera Introduction5
03 Set up the Camera - Plan A (Bluetooth)7
04 Set up the Camera - Plan B (Soft-AP)10
05 Test the Signal and All Set-up13
06 Install the Camera14
07 Introduction to basic functions15
08 FAQ16
09 Warranty Activation17

#### 01 Download & Register the Application

Here are two methods to download the "**AJCloud**" app. Please choose the one that is convenient for you.

Method 1: Scan the following QR codes according to the mobile system to download the app.



Method 2: You can go to the app store and search for AJCloud to download the app.



\*The app is free. If you receive a prompt to pay when downloading, please contact customer service for assistance.



**Online Customer Service** 

## Register the AJCloud Account

\*Please connect the device to the app successfully before installing it in the desired location.

#### Register an AJCloud account using an email address.





\* If you cannot find the verification code in your e-mail, please try to register with another e-mail address.

\* If you are unable to register an APP account using email , please scan the QR code below to contact online customer service.

-4-



Online Customer Service

#### 02 Camera Introduction

#### Step 1: Turning on the Camera



Power up using the USB DC adapter included in the box.

After powering on for the first time, it will perform a self-check rotation and the indicator light will light up.

LED indicator

-5-

#### Step 2: Resetting the device

Please press and hold the reset button for **8-10 seconds** before connecting the camera, wait a few seconds for the voice prompt.

After successful reset, the device will perform self check rotation, and the indicator light will flash.

**TF Card**: It is recommended to use a genuine TF card with a capacity of 32–128GB, Class 10, 32FAT format ,which is suitable for camera use.

Reset Button



Note: Please reset the device before each reconnection. It is recommended to place the device near the router for the initial connection.

## 03 Set up the Camera -Plan A (Bluetooth)

First, please turn on the Bluetooth function on your phone.

-7-





IOS



#### Then run the "AJCloud" APP to connect to the camera.



-8-



\* For detailed connection methods of Plan B, please refer to page 10.

### 04 Set up the Camera - Plan B (Soft-AP/Hotspot connection)

-10-



<b>10.0</b>		all 👻	<b>6</b>
÷	Connect to the de-	vice hotspot	
	al V Jone Chemis WAM		
	WLAN		
	<ul> <li>AJCXXXX</li> </ul>	1	
	DIDDEE ANETHOM.		
	Aptinue-2.40		
	Actival-60		
	alimiter		
	and-free	* (1)	
	Chinahan Autob	0	
	Arter the connection is succ AJCloud ap	estia, Jetum to the	
	Go to setti	P.	
	Connect the device	automatically	



If you cannot find the device's hotspot, pls reset the device and try again.

17:24 - • AJClou	0	.ıli 🗢 🕼
< Sett	Wi-Fi	Edit
Wi-Fi		
✓ AJCDA9KNX Unsecured Netw	LSJF5SR ork	<b>∻</b> (j)
Go back to	o the AJ(	Cloud APP
OTHER NETWORKS	5	
1330		🔒 🗢 🚺
1806YGSS		ê 🗢 🚺
ChinaNet-99	dF	ê 후 🚺
ChinaNet-r6	2i	ê 🕈 🚺
FYD1810		🕯 🗢 🚺
IPCAM-1137	19	🔒 🗢 🚺
Tineco_0145		
XDYY		ê 🗢 🚺
XINDA		ê 🕈 🚺
瑞康羊奶		ê 🗟 î

17:25 ←	Wi-Fi Settings	<b>₹</b> 40
Choose a netw	ork	
IPCAM-113719		()
XINDA		()
1809-DC	Select your 2.4GH	z WiF
		()
After con notspot, APP the WiFi setti	nnecting to the c when you return f page will jump t ng interface	levice to the o the
After con notspot, APP the WiFi setti	nnecting to the c when you return f page will jump t ng interface	levice to the to the
After con notspot, APP the WiFi setti Ruikang 1806YGSS	nnecting to the c when you return t page will jump t ng interface	levice to the o the
After con notspot, APP the WiFi setti Ruikang 1806YGSS (xE7/x91/x9E/x	nnecting to the c when you return t page will jump t ng interface	evice to the o the
After con hotspot, APP the WiFi setti Ruikang 1806YGSS \xE7\x91\x9E\x Tineco_0145	nnecting to the c when you return 1 page will jump t ng interface esw8a\w87\xe7\x8E\x8a\we5\xasy 86	evice to the o the e
After con hotspot, APP the WiFi setti Ruikang 1806YGSS VxE7/x91/x9E/x Tineco_0145 DIRECT-93-HP L	nnecting to the c when you return f page will jump t ng interface E5\x8A\x87\xE7\x8E\x8A\xE5\xA5\x 86	evice to the o the © © © ©



\*You can also scan the QR code below to watch the connection video or contact customer service.



**Operation Guidance Video** 



**Online Customer Service** 

## 05 Test the Signal and All Set-up

16:24I ? (1) Pair succeeded	16:25 .ul r E Wi-Fi signal
Name the IP Camera	Good
AJCDA9LNCKTHVGZU	Wi-Fi signal at current location
Front door Back yard Living room	
Baby Pet Kitchen Garage	If the WiFi signal is weak, move the
Office	camera to test again until it's strong
ок	
	ок

\*If you would like to know more detailed product information, please visit our official website to download the detailed user manual.



-13

#### 06 Install the Camera



• For outdoor use, the camera MUST be installed upside down for better waterproof performance and better PIR motion sensor's efficiency.

• Install the camera 2-3 meters (7-10 ft) above the ground. This height maximizes the detection range of the PIR motion sensor.

• For better motion detection performance, please install the camera angularly.

NOTE: If a moving object approaches the PIR sensor vertically, the camera may fail to detect motion.

#### 07 Introduction to basic functions



2 Adjust motion detection sensitivity.



-15-



③ Set alarm time period and alarm notification form.



## 08 FAQ

#### (1) The camera cannot connect to WiFi:

1. Make sure the camera is powered on properly. (If there is an indicator light on the camera).

2. When connecting for the first time, it's recommended to press and hold the camera reset button 8s-10s to reset.

3. An overly long WiFi password or one that includes special symbols may prevent the app from properly recognizing the password.

Warm reminder: Some cameras only support 2.4GHz WiFi and do not support 5GHz WiFi.

#### (2) The camera disconnected while in use:

1. The camera is too far from the router, causing poor WiFi signal reception. Pls take the camera to the router for resetting and re-adding, and check if the WiFi signal value is stable.

2. There are other interference between the camera and the router, such as walls, glass, and other electronic products.

3. The camera is not powered on properly. Please replace the power supply and try again.

Do you have any other questions? Please feel free to contact us anytime!



Online Customer Service

-16-

## 09 Warranty Activation

We offer you 12 months free warranty. You can activate your warranty by choosing one of the following methods!

#### Method 1:

(1) Scan the QR code below to submit a warranty activation application.



## Free Warranty

#### Method 2:

(1) Send us an email with the subject line "Warranty Activation".

(2) Include your order number and order date in the email content.

Note:

1. Please make sure your order number and email are correct so that we can activate the warranty for you successfully.

2. We will notify you of the result of warranty activation within 12 hours.

## **Contact us**

www.jennov.com

🖂 support@jennov.com

🕲 U.S Hotline: +1 3239021978



## Everything is in view

